


Spare parts for digital height gage 1150 series



Part NO.	Code	Description
1	SP-STOP-1150-1	End stop plate (-300)
	SP-STOP-1150-2	End stop plate (-500/-600)
	SP-STOP-1150-3	End stop plate (-1000/-1500/-2000)
2	SP-STOP-1150-SCREW-1	Locking srew for Part NO.1(-300)
	SP-STOP-1150-SCREW-2	Locking srew for Part NO.1(-500/-600)
	SP-STOP-1150-SCREW-3	Locking srew for Part NO.1(-1000/-1500/-2000)
3	SP-ADJUST-1150-1	Fine adjustment device (-300)
	SP-ADJUST-1150-2	Fine adjustment device (-500/-600)
	SP-ADJUST-1150-3	Fine adjustment device (-1000/-1500/-2000)
4	SP-INTERFACE COVER-1150-1	Interface cover (-300)
	SP-INTERFACE COVER-1150-2	Interface cover (-500/600)
	SP-INTERFACE COVER-1150-3	Interface cover (-1000/1500/2000)
5	SP-LOCK-1150-1	Locking srew (-300)
	SP-LOCK-1150-2	Locking srew (-500/-600)
	SP-LOCK-1150-3	Locking srew (-1000/-1500/-2000)
6	SP-CHIP-1150-1	Display unit for 1150-300 (include dust brush)
	SP-CHIP-1150-2	Display unit for 1150-500/-600 (include dust brush)
	SP-CHIP-1150-3	Display unit for 1150-1000/-1500/-2000 (include dust brush)
7	SP-COVER-1150-1	Battery cover (-300)
	SP-COVER-1150-2	Battery cover (-500/-600)
	SP-COVER-1150-3	Battery cover (-1000/-1500/-2000)
8	SP-STICKER-G300	Sticker (-300)
	SP-STICKER-H500	Sticker (-500)
	SP-STICKER-G600	Sticker (-600)
	SP-STICKER-G1000	Sticker (-1000)
	SP-STICKER-H1500	Sticker (-1500)
9	SP-CLAMP-1150-1	Clamp (-300)
	SP-CLAMP-1150-2	Clamp (-500/-600)
	SP-CLAMP-1150-3	Clamp (-1000/1500/2000)
10	SP-HOLDER LOCK-1150	Holder Lock
11	SP-HOLDER-1150-1	Indicator holder with 8mm diameter (-300)
	SP-HOLDER-1150-2	Indicator holder with 8mm diameter (-500/-600)
	SP-HOLDER-1150-3	Indicator holder with 8mm diameter (-1000/-1500/-2000)
	SP-1150-300-CL-I	Indicator holder with 3/8" diameter (-300E)
	SP-1150-600-CL-I	Indicator holder with 3/8" diameter (-500E/-600E)
	SP-1150-1000-CL-I	Indicator holder with 3/8" diameter (-1000E/-1500E/-2000E)

12	SP-STRIP-1150-1	Copper strip for 1150-300
	SP-STRIP-1150-2	Copper strip for 1150-500/-600
	SP-STRIP-1150-3	Copper strip for 1150-1000/-1500/-2000
13	SP-DISPLAY-1150-1	Display screen for 1150-300
	SP-DISPLAY-1150-2	Display screen for 1150-500/-600
	SP-DISPLAY-1150-3	Display screen for 1150-1000/-1500/-2000
14	SP-RED BUTTON-1150-1	On/off switch button for 1150-300
	SP-RED BUTTON-1150-3	On/off switch button for 1150-1000/-1500/-2000
15	SP-PLASTIC COVER-1150-1	Plastic cover for 1150-300 (not include dust brush and NO.13)
	SP-PLASTIC COVER-1150-2	Plastic cover for 1150-500/-600 (not include dust brush and NO.13)
	SP-PLASTIC COVER-1150-3	Plastic cover for 1150-1000/-1500/-2000 (not include dust brush and NO.13)
16	SP-GRAY BUTTON-1150-1	Gray button for 1150-300
	SP-GRAY BUTTON-1150-3	Gray button for 1150-1000/-1500/-2000
17	SP-COPPER BACKING-1150-1	Copper backing for 1150-300
	SP-COPPER BACKING-1150-2	Copper backing 1150-500/-600
	SP-COPPER BACKING-1150-3	Copper backing 1150-1000/-1500/-2000
18	SP-RUBBER STRIP-1150-600	Rubber strip for 1150-500/600